

STYRENHET / STEUERINHEIT CONTROLLER / UNITÉ DE CONTRÔLE		CTC EcoZenith i255	CTC EcoZenith i360	CTC EcoVent i360F	CTC EcoZenith i555 Pro	CTC EcoPart Pro (i425/i430/i435)	CTC EcoLogic L	CTC EcoLogic M	CTC EcoLogic S	CTC EcoZenith i250	CTC EcoZenith i350	CTC EcoVent i350F	CTC EcoZenith i550 Pro	CTC EcoLogic Pro/Family	CTC Basicstyrning
		LUFT/VATTENVÄRMEPUMP - AIR-TO-WATER HEAT PUMP - LUFT/WASSER-WÄRMEPUMP - POMPE À CHALEUR AIR/EAU													
CTC EcoAir 406	1x230V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoAir 406	3x400V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoAir 408	1x230V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoAir 408	3x400V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoAir 410	1x230V	x			x	x	x	x	x	x			x	x	x
CTC EcoAir 410	3x400V	x			x	x	x	x	x	x			x	x	x
CTC EcoAir 415	1x230V				x	x	x	x	x				x	x	x
CTC EcoAir 415	3x400V				x	x	x	x	x				x	x	x
CTC EcoAir 420	1x230V				x	x	x	x	x				x	x	x
CTC EcoAir 420	3x400V				x	x	x	x	x				x	x	x
CTC EcoAir 510M	1x230V	x	x	x			x	x	x	x	x	x		x	
CTC EcoAir 510M	3x400V	x	x	x					x	x	x	x			
CTC EcoAir 520M	3x400V	x	x	x	x		x	x	x	x	x	x	x	x	
CTC EcoAir 610M	3x400V	x	x	x			x	x	x	x	x	x		x	
CTC EcoAir 614M	3x400V	x	x	x	x		x	x	x	x	x	x	x	x	
CTC EcoAir 622M	3x400V	x	x	x	x		x	x	x	x	x	x	x	x	
CTC CombiAir 6M	230V		x				x	x							
CTC CombiAir 8M	230V		x				x	x							
CTC CombiAir 12M	230V		x				x	x							
CTC CombiAir 16M	230V		x				x	x							

STYRENHET / STEUERINHEIT CONTROLLER / UNITÉ DE CONTRÔLE		CTC EcoZenith i255	CTC EcoZenith i360	CTC EcoVent i360F	CTC EcoZenith i555 Pro	CTC EcoPart Pro (i425/i430/i435)	CTC EcoLogic L	CTC EcoLogic M	CTC EcoLogic S	CTC EcoZenith i250	CTC EcoZenith i350	CTC EcoVent i350F	CTC EcoZenith i550 Pro	CTC EcoLogic Pro/Family	CTC Basicstyrning
		BERGVÄRMEPUMP - GROUND SOURCE HEATPUMP - ERDWÄRMEPUMP - CHAUFFAGE GÉOTHERMIQUE													
CTC EcoPart 406 1x230V	1x230V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 406 3x400V	3x400V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 408 1x230V	1x230V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 408 3x400V	3x400V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 410 1x230V	1x230V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 410 3x400V	3x400V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 412 1x230V	1x230V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 412 3x400V	3x400V	x	x	x	x	x	x	x	x	x	x	x	x	x	x
CTC EcoPart 414 1x230V	1x230V				x	x	x	x	x				x	x	x
CTC EcoPart 414 3x400V	3x400V				x	x	x	x	x				x	x	x
CTC EcoPart 417 1x230V	1x230V				x	x	x	x	x				x	x	x
CTC EcoPart 417 3x400V	3x400V				x	x	x	x	x				x	x	x
CTC EcoPart 425 Basic 1x230V	1x230V				x	x	x	x					x	x	
CTC EcoPart 425 Basic 3x400V	3x400V				x	x	x	x					x	x	
CTC EcoPart 430 Basic 1x230V	1x230V				x	x	x	x					x	x	
CTC EcoPart 430 Basic 3x400V	3x400V				x	x	x	x					x	x	
CTC EcoPart 435 Basic 1x230V	1x230V				x	x	x	x					x	x	
CTC EcoPart 435 Basic 3x400V	3x400V				x	x	x	x					x	x	
CTC EcoPart 612M 3x400V	3x400V		x	x	x	x	x	x	x				x	x	
CTC EcoPart 616M 3x400V	3x400V		x	x	x	x	x	x	x				x	x	

MED INBYGGD STYRNING FÖR ANTAL VÄRMEPUMPAR WITH BUILT-IN CONTROL FOR NUMBER OF HEAT PUMPS MIT EINGEBAUTER STEUERUNG FÜR ANZAHL DER WÄRMEPUMPEN AVEC CONTRÔLE INTÉGRÉ DU NOMBRE DE POMPES À CHALEUR	
CTC EcoZenith i250 / i255	1
CTC EcoZenith i350 / i360	1
CTC EcoVent i350F / i360F	1
CTC EcoZenith i550 / i555 Pro	3
CTC EcoLogic Pro / L **	10
CTC EcoLogic Family / M	2
CTC Basicstyrning / EcoLogic S	1
CTC EcoPart Pro *	10
* 1 CTC EcoPart Pro/Basic = 2 ** CTC CombiAir = 1-4 ≠ 5-10	